



Manual for setting the time zone for the Almemo 500

Revision: R0

Date: 12.03.19

Development

1. First of all the program Timezone Configurator must be started

The screenshot shows the 'Almemo500 Timezone Configurator' window. It has a title bar with a green icon and a close button. The window is divided into three main sections. The top section, 'Almemo500 Connection:', contains an 'IP:' label, a text box with '192 . 168 . 1 . 100', and a 'Connect' button. The middle section, 'Set TimeZone Settings:', contains a 'Set TimeZone:' label, a list box with various time zones (Africa/Abidjan, Africa/Accra, Africa/Addis_Ababa, Africa/Algiers, Africa/Asmara, Africa/Bamako, Africa/Bangui, Africa/Banjul, Africa/Bissau, Africa/Blantyre, Africa/Brazzaville, Africa/Bujumbura), a 'Write TimeZone Settings' button, and a 'Current TimeZone Settings:' section with an empty text box and a 'Read TimeZone Settings' button. The bottom section, 'Communication Log:', contains a large empty text area. A 'Close' button is located at the bottom right of the window.

2. Next please enter the IP address of the Almemo 500 and click on "Connect" to connect

This screenshot shows a close-up of the 'IP:' label, a text box containing '192 . 168 . 1 . 204', and a 'Connect' button. The 'Connect' button is highlighted with a blue border.

3. Then select a location from your own time zone in the time zone list and click on "Write TimeZone Settings" to set it. (The list is sorted by continent/city)

This screenshot shows a close-up of the 'Set TimeZone:' label and a list box. The list box contains various time zones, and 'Asia/Seoul' is selected and highlighted in blue. Below the list box is a 'Write TimeZone Settings' button.


- Then click the "Read TimeZone Settings" button, if the time zone has been set correctly, the set time zone will appear in this field

Current TimeZone Settings:

Asia/Seoul (KST, +0900)

Read TimeZone Settings

- Please REBOOT now the Almemo 500
- After the reboot is done, start the ALMEMO 500 App and connect to the ALMEMO 500
- Click on "Settings", then select the "Settings" menu in the settings overview and set the time and date here



- Please REBOOT now the Almemo 500 again